

**GATES HYDRAULIC**

**SPRING GUARDS**

**How To Order Gates Spring Guards**

Refer to the appropriate Spring Guard Selection Chart for ordering by Part Number or Product Number. Find the proper Dash Number in far left-hand column, and move horizontally until you arrive in the vertical column headed by the appropriate hose description. At this point, you'll find the Part Number or Product Number for the recommended Spring Guard.


To order—Specify the Part/Product Number and the spring guard length desired (in feet).

NOTE: For your convenience, both Selection Charts have been simplified. In some cases, it may be possible to use the next smaller spring guard. To check if this is possible, compare O.D. of hose to I.D. of spring guard. Allow 1/32" for installation.

DASH SIZE	RB&H# PREFIX	EFG6K G6K EFG5K G5K, CPS	12LW 16LW C12M	G2/C2H MCPB G2L G2AT-HMP	G1 G1H M2T <sup>®</sup>	M3K	C3 C3H	C6 C6H	RLA	C5C C5D	C5E	G4H GMV	RLC	LOC LOL+	C7S C7SNC C8S C8SNC
-3	7277-	-	-	0533	0500	-	0533	0500	0500	-	-	-	-	0500	0500
-4	7277-	-	-	0501	0533	0500	0533	0533	0533	0533	0500	-	-	0500	0500
-5	7277-	-	-	-	0502	-	0502	0533	0501	0501	0533	-	-	0501	0533
-6	7277-	-	-	0534	0534	0501	0534	0502	0502	0534	0501	-	-	0534	0502
-8	7277-	-	0506	0505	0504	0503	0506	0503	0504	0503	0534	-	-	0534	0504
-10	7277-	-	-	0530	0506	0530	-	0505	0506	0506	0504	-	-	0506	-
-12	7277-	-	0508	0507	0507	0507	0532	0507	0507	0507	0506	0532	-	0530	0507
-14	7277-	-	-	-	-	0520	-	-	-	-	-	-	-	-	-
-16	7277-	0520	0520	0520	0520	-	0509	0520	0520	0532	0508	0509	0525	-	0532
-18	7277-	-	-	-	-	-	-	-	-	-	-	-	0531	-	-
-20	7277-	0527	0527	0527	0531	-	0531	-	-	0520	-	0527	0527	-	-
-24	7277-	0528	0528	0528	0527	-	-	-	-	0525	-	0528	0528	-	-
-28	7277-	-	-	-	-	-	-	-	-	-	-	-	0526	-	-
-32	7277-	0526	0526	0526	0526	-	-	-	-	0528	-	0526	0526	-	-

**Plated Wire Spring Guard**

RB&H #	"A" (IN.) (+.015)	"C" (IN.)	"P" (IN.)
7277-0521	.550	14 (.080)	7/32
7277-0510	.676	14 (.080)	7/32
7277-0535	.682	16 (.065)	7/32
7277-0511	.738	14 (.080)	7/32
7277-0512	.852	14 (.080)	7/32
7277-0513	.915	14 (.080)	7/32
7277-0514	.977	14 (.080)	7/32
7277-0515	1.040	14 (.080)	7/32
7277-0522	1.122	14 (.080)	7/32
7277-0516	1.278	11 (.120)	11/32
7277-0517	1.340	11 (.120)	11/32
7277-0518	1.578	11 (.120)	11/32
7277-0519	1.625	11 (.120)	11/32
7277-0524	1.847	14 (.080)	13/32
7277-0523	2.112	14 (.080)	13/32
7277-0548	2.12	11 (.120)	11/32



**Flat Armour Spring Guard**

RB&H #	AUTOMOTIVE REF #	"A" (IN.) (+.015)	"B" (IN.)	"C" (IN.)	"P" (IN.)
7277-0500	82530	.550	.019	3/8	1/2
7277-0533	82553	.609	.032	1/4	3/8
7277-0501	82521	.656	.019	3/8	1/2
7277-0502	82532	.719	.019	3/8	1/2
7277-0534	82554	.797	.032	3/8	1/2
7277-0503	82533	.812	.028	1/4	3/8
7277-0504	82534	.875	.028	1/2	5/8
7277-0505	82535	.953	.028	1/2	5/8
7277-0506	82536	1.000	.028	1/2	5/8
7277-0530	82556	1.093	.028	1/2	5/8
7277-0507	82537	1.219	.028	1/2	5/8
7277-0508	82538	1.281	.028	1/2	5/8
7277-0532	82552	1.375	.028	1/2	5/8
7277-0520	82539	1.562	.028	1/2	5/8
7277-0509	82540	1.625	.028	1/2	5/8
7277-0529	82529	1.687	.028	1/2	5/8
7277-0525	82525	1.797	.028	1/2	5/8
7277-0531	82531	1.844	.028	1/2	5/8
7277-0527	82527	2.093	.028	1/2	5/8
7277-0528	82528	2.343	.028	1/2	5/8
7277-0526	82526	2.875	.028	1/2	5/8

