

**BRASS FITTINGS**

**BRASS HOSE BARB FITTINGS**

**Brass Hose Barb Fittings**

(LOW PRESSURE HOSE APPLICATIONS)

**Male NPTF Pipe**



**SPECIFICATIONS**

RB&H #	HOSE L.D. (IN.)	THREAD SIZE (IN.)
HN12X2X2	1/8	1/8
HN12X2X4	1/8	1/4
HN12X3X2	3/16	1/8
HN12X3X4	3/16	1/4
HN12X4X2	1/4	1/8
HN12X4X4	1/4	1/4
HN12X4X6	1/4	3/8
HN12X5X2	5/16	1/8
HN12X5X4	5/16	1/4
HN12X5X6	5/16	3/8
HN12X6X2	3/8	1/8
HN12X6X4	3/8	1/4
HN12X6X6	3/8	3/8
HN12X6X8	3/8	1/2
HN12X6X12	3/8	3/4
HN12X8X4	1/2	1/4
HN12X8X6	1/2	3/8
HN12X8X8	1/2	1/2
HN12X8X12	1/2	3/4
HN12X10X6	5/8	3/8
HN12X10X8	5/8	1/2
HN12X10X12	5/8	3/4
HN12X12X8	3/4	1/2
HN12X12X12	3/4	3/4
HN12X16X12	1	3/4
HN12X16X16	1	1

**Female NPTF Pipe Rigid**



**SPECIFICATIONS**

RB&H #	HOSE L.D. (IN.)	THREAD SIZE (IN.)
HN14X2X2	1/8	1/8
HN14X2X4	1/8	1/4
HN14X3X2	3/16	1/8
HN14X3X4	3/16	1/4
HN14X4X2	1/4	1/8
HN14X4X4	1/4	1/4
HN14X4X6	1/4	3/8
HN14X5X2	5/16	1/8
HN14X5X4	5/16	1/4
HN14X5X6	5/16	3/8
HN14X6X2	3/8	1/8
HN14X6X4	3/8	1/4
HN14X6X6	3/8	3/8
HN14X6X8	3/8	1/2
HN14X8X4	1/2	1/4
HN14X8X6	1/2	3/8
HN14X8X8	1/2	1/2
HN14X12X12	3/4	3/4

**Male NPTF Pipe Swivel**



**SPECIFICATIONS**

RB&H #	HOSE L.D. (IN.)	THREAD SIZE (IN.)
HN13X4X4	1/4	1/4
HN13X6X6	3/8	3/8

**Female NPSM Pipe Ball Seat (30°) Type**



**SPECIFICATIONS**

RB&H #	HOSE L.D. (IN.)	THREAD SIZE (IN.)
HN24X2X2	1/8	1/8
HN24X3X2	3/16	1/8
HN24X3X4	3/16	1/4
HN24X4X2	1/4	1/8
HN24X4X4	1/4	1/4
HN24X4X6	1/4	3/8
HN24X5X4	5/16	1/4
HN24X6X4	3/8	1/4
HN24X6X6	3/8	3/8
HN24X6X8	3/8	1/2
HN24X8X6	1/2	3/8
HN24X8X8	1/2	1/2
HN24X12X12	3/4	3/4

**Male NPTF Pipe (90°)**



**SPECIFICATIONS**

RB&H #	HOSE L.D. (IN.)	THREAD SIZE (IN.)
HN16X4X2	1/4	1/8
HN16X4X4	1/4	1/4
HN16X5X4	5/16	1/4
HN16X6X2	3/8	1/8
HN16X6X4	3/8	1/4
HN16X6X6	3/8	3/8
HN16X8X4	1/2	1/4
HN16X8X6	1/2	3/8
HN16X10X6	5/8	3/8
HN16X10X8	5/8	1/2

**Female (45° Flare) Swivel**



**SPECIFICATIONS**

RB&H #	HOSE L.D. (IN.)	THREAD SIZE (IN.)
HN44X3X3	3/16	3/8 - 24
HN44X3X4	3/16	7/16 - 20
HN44X4X4	1/4	7/16 - 20
HN44X4X5	1/4	1/2 - 20
HN44X4X6	1/4	5/8 - 18
HN44X5X5	5/16	1/2 - 20
HN44X5X6	5/16	5/8 - 18
HN44X6X6	3/8	5/8 - 18
HN44X6X8	3/8	3/4 - 16
HN44X8X8	1/2	3/4 - 16
HN44X8X10	1/2	7/8 - 14

**BRASS FITTINGS**

**BRASS HOSE BARB FITTINGS**

**SPECIFICATIONS**

RB&H #	HOSE L.D. (IN.)	THREAD SIZE (IN.)
HN42X4X4	1/4	7/16 - 20
HN42X6X6	3/8	5/8 - 18

**Male SAE  
(45° Flare)**



**SPECIFICATIONS**

RB&H #	THREAD SIZE (1) (IN.)	MALE PIPE (2) (IN.)
156X9*	9/16 - 18	-

**Welding  
Hose Adapter  
(right hand  
thread,  
oxygen)**



**SPECIFICATIONS**

RB&H #	HOSE L.D. (IN.)	THREAD SIZE (IN.)
HN45X6X6	3/8	9/16 - 18

**Female JIC  
(37° Flare)  
Swivel**



**SPECIFICATIONS**

RB&H #	THREAD SIZE (1) (IN.)	MALE PIPE (2) (IN.)
158X6X4	9/16 - 18	1/4
158X6X6	9/16 - 18	3/8
158X9*	9/16 - 18	-

**Welding Hose  
Adapter  
(left hand  
thread,  
acetylene)**

\* Union adapter

**SPECIFICATIONS**

RB&H #	HOSE L.D. (IN.)
HN32X3	3/16
HN32X4	1/4
HN32X5	5/16
HN32X6	3/8
HN32X8	1/2
HN32X10	9/8
HN32X12	3/4

**Hose Splicer**



**SPECIFICATIONS**

RB&H #	MALE BALL SEAT (1) (IN.)	MALE PIPE (2) (IN.)
150X2X2	1/8	1/8
150X4X2	1/4	1/8
150X4X4	1/4	1/4
150X4X6	1/4	3/8
150X6X4	3/8	1/4
150X6X6	3/8	3/8
150X6X8	3/8	1/2
150X8X6	1/2	3/8
150X8X8	1/2	1/2
150X12X12	3/4	3/4
237X4*	1/4	-

**Male Pipe  
(30° ball seat)  
Male NPTF  
Adapter**



\* Union adapter

**SPECIFICATIONS**

RB&H #	HOSE L.D. (IN.)	NF THREAD SIZE (IN.)
HN52X3X6	3/16	9/16 - 18
HN52X4X6	1/4	9/16 - 18
HN52X5X6	5/16	9/16 - 18
HN52X6X6	3/8	9/16 - 18

**Welding Hose  
Coupling  
(right hand  
thread,  
oxygen)**



**SPECIFICATIONS**

RB&H #	HOSE L.D. (IN.)	NF THREAD SIZE (IN.)
HN54X3X4	3/16	3/8 - 24
HN54X3X6	3/16	9/16 - 18
HN54X4X6	1/4	9/16 - 18
HN54X5X6	5/16	9/16 - 18
HN54X6X6	3/8	9/16 - 18

**(left hand  
thread,  
acetylene)**