

CLAMPS

STEAM & AIR

Heavy Duty Hose Clamps - Steam & Air

2 Bolt



4 Bolt Stem

The bolts used in the "Boss" interlocking clamps are not standard bolts. These bolts can be re-torqued, but it is not recommended that they be reused. Do not lubricate nuts and bolts.

SPECIFICATIONS

RB&H #	SIZE (IN.)	O.D. FROM: (IN.)	O.D. TO: (IN.)	TORQUE
CD/D	3/8	44/64	56/64	6
DD/D	1/2	52/64	60/64	6
B-4/D	1/2	60/64	1 4/64	12
B-5/D	1/2	1 4/64	1 12/64	12
BU-9S/D	3/4	1 10/64	1 18/64	21
BU-9/D	3/4	1 12/64	1 20/64	21
B-9/D	3/4	1 20/64	1 32/64	21
B-10/D	3/4	1 32/64	1 44/64	21
BU-14/D	1	1 34/64	1 46/64	21
B-14/D	1	1 44/64	1 60/64	21
B-15/D	1	1 60/64	2 8/64	21
BU-18/D	1 1/4	1 32/64	1 50/64	40
BU-19/D	1 1/4	1 50/64	2 8/64	40
B-19/D	1 1/4	2 8/64	2 24/64	40
BU-22/D	1 1/2	1 52/64	2	40
B-22/D	1 1/2	2	2 14/64	40
BU-24/D	1 1/2	2 12/64	2 24/64	40

"KING" CLAMPS

"King" Single Bolt Clamps



SPECIFICATIONS

RB&H #	FIT HOSE O.D. (IN.)	
	FROM:	TO:
2/D	7/8	1
3/D	31/32	1 1/8
4/D	1 1/16	1 3/16
5/D	1 5/32	1 1/4
6/D	1 1/4	1 3/8
7/D	1 11/32	1 7/16
8/D	1 7/16	1 9/16
9/D	1 17/32	1 11/16
10/D	1 21/32	1 3/4
11/D	1 3/4	1 7/8
12/D	1 7/8	2 1/32
13/D	2	2 1/8
14/D	2 1/8	2 9/32
15/D	2 1/4	2 13/32
16/D	2 3/8	2 1/2
17/D	2 1/2	2 5/8
18/D	2 5/8	2 7/8
19/D	2 7/8	3 1/16
20/D	3 1/16	3 1/4
21/D	3 1/4	3 7/16
22/D	3 7/16	3 5/8
23/D	3 5/8	3 13/16
24/D	3 13/16	4 1/8
25/D	4 1/8	4 5/16
26/D	4 1/4	4 1/2